



CVR (Chrome Valet Rod) CTR (Chrome Tie Rack) CBSR (Chrome Belt/Scarf Rack) Installation

Tools Needed: Philips screwdriver, Allen wrench (supplied)

Instructions:

Loosen the set screws in each post using the supplied allen wrench.

Mount the posts to the partition using 2 euro screws (see pic below). Align so that the large holes are facing front and back and set screws are up.

Slide the rod assembly into the posts and tighten set screws at desired depth.

Illustration shown is for the CVR, CBSR and CTR are similar installation.

Notes: For left hand orientation on CTR and CBSR, remove philips screw at rear, pull rack out, loosen 2 allen set screws, flip rack and reinstall in reverse order.



Euro Screw

LIFESPAN
closets
organize your life