



Ironing Board Installation

Tools Needed: 10mm wrench, Philips screwdriver, 5mm allen wrench (included)

Separate drawer slides by extending them fully, and depressing the plastic release lever.

Use 4 euro screws (pictured below) to attach the outer slides to the closet system. Start with the 2nd hole of the slide aligning with the front hole of the partition.

Using the 5mm allen wrench and 10mm wrench, remove the board and front support.

Guide the inner slides and frame onto the mounted outer slides.

Install pre drilled drawer front onto slide flanges using included #8 screws.

Re-install the board and support brackets. Attach support bracket to drawer face using #8 screws.

Fold ironing board and slides into drawer checking for proper fitment. Make adjustments to bolts for alignment.

Operation Notes: Lift and release latch on bottom side of board before folding. Lift drawer head slightly before pushing completely into closet system.



Euro Screw

LIFESPAN
closets
organize your life