



Wedgerail Installation

Tools Needed: Stud finder, screw gun and bit, $\frac{1}{8}$ " drill bit, level, pencil

Instructions:

Make a level line 79" up from the floor. This will mark the bottom of the top rail.
(This will set the overall closet height at 86").

Using a stud finder, mark the wall stud locations above the line you have marked. Verify stud location by drilling through surface to test for a stud underneath.

Use 2 partitions hanging on the top wedgerail to hang the lower wedgerail.

Cut wedgerail to the length of the closet minus $\frac{1}{8}$ ". Mark corresponding stud locations onto rail in the center of groove. Drill a $\frac{1}{8}$ " pilot hole on the mark. Do not use sheet rock screws. Drive screws flush to (or slightly recessed from) the surface of the wedgerail groove.

Note: these dimensions are given for standard height assembly, wedgerail can be hung higher or lower to adjust final closet system height

